

Installing your RFID Tags

Choose a suitable location to install the tag on the centre of the rear bumper. Recommended mounting position for TAG – center of the truck rear bumper, tag mounted vertically. Tags must be applied with 2 self tapping screws.

Ideal Installation



Incorrect Installation



Find a smooth flat surface – do not attempt to mount tags over welds or curved/warped surfaces. Ensure that the location is suitable for the self tapping screws. Once a location is identified, clean the surface to remove any dirt or loose paint. Leave to dry and then attach the tag to the prepared surface. Once the tag is attached, screw in the self tapping screws fully, making sure they have are properly secured into the bumper.

Important Information:

Metal surfaces in direct proximity to the tag can reduce the tag's range of function. Tags should therefore not be mounted in metal recesses or corners. Also ensure not to over tighten TAG's which can cause cracking of the rear case and subsequent water exposure resulting in failure of the device.

